



STOP READ THIS WARNING!

Make sure you test fit these exhaust components BEFORE any cutting, welding or unnecessary bending is done. Once modified, the components of the system are NOT RETURNABLE.

If you are unsure of the proper installation procedures or fitment, please contact a qualified exhaust shop or call our tech lines toll free at 800-421-3890 or visit our installation gallery at: www.pypesexhaust.com/install

One of our experienced exhaust techs will be glad to assist you in any way. Thanks and enjoy you new...

Pypes Performance Exhaust!

SCROLL DOWN FOR INSTRUCTIONS



SME11S

409 stainless steel header/cross-member back exhaust system for
1970-1974 Barracuda E-bodies

SME11S: 2-1/2" System w/ x-pipe



Pypes Performance Exhaust
2705 Clemens Rd B103 Hatfield, PA 19440
www.pypesexhaust.com 800-421-3890

Thanks again for purchasing your new 409 Stainless Steel Pypes Performance Exhaust header/cross-member back system. Please be sure to confirm all the components in the kit were received in your shipment before beginning installation. These kits will include (1) X-pipe kit, (2) Street Pro Mufflers, (2) tailpipes, (2) collector extensions, (2) muffler hangers, (2) tailpipe hangers, (10) clamps. If you find any component missing, please contact our office at 800-421-3890 for replacement. Installation of this kit will require some simple hand tools; box wrenches, deep sockets w/ ratchet, extension, a saws-all and some penetrating lubricant. For a quicker and tighter installation, air tools are recommended. Technical assistance is available both online at www.pypesexhaust.com or 800-421-3890. Also our online Installation Gallery is a great assistant during your installation, www.pypesexhaust.com/pictures.html.

1. Begin by placing the vehicle on a lift or four jack stands at maximum height to aid in an easier installation. To help ease the installation, pre-fit all the components into a complete system on your garage floor, using the diagram provided.

2. First, remove the existing exhaust system from the headers or the exhaust manifolds back. You can also remove any hanger mounted to the frame as your new kit includes new hangers.

3. Now it's time to install your new components. You will be starting from the back of the car and working your way forward. Begin by installing the new tailpipes. Temporarily hang the tails over the rear axle. These tailpipes are designed to mount in the factory rubber tail pipe hanger. If they are not present you can utilize the universal rubber strap style hangers provided. Slide the mufflers onto the tailpipes placing a support under them. You will be clamping a hanger to the back of the muffler neck and attaching it to the under body of the car. In some applications, your factory hangers may be used.

4. Next, install the x-pipe. This is where trimming of the front legs may be required for the optimum fit. Install the fixed rear legged "X" onto the mufflers first. Your center "X" should be positioned approx 8-12 inches behind the tail shaft of your transmission and centered under the driveshaft. Also, the center plate in the "X" has an arrow stamp which must point forward. Next, slide the front legs into the x-pipe. They should end somewhere close to the humps in your transmission cross-member. These may need to be trimmed to fit the width of your headers or optional down-pipes. Narrowing width will require trimming to leg as it slides into the center "X". Be extra careful when measuring and cutting. A helpful tip: Line up the front legs under the center "X" to mark your cut lines making sure to line them up with you headers or down pipes. Finish the system by connecting the front legs of the x-pipe to the headers (collector reducers) utilizing the two 1ft connection pipes. Trimming the length may be required. If down pipes are used, make sure they end close to the rear side of the transmission cross member. If they are too long they must be trimmed. Some header applications require custom collectors due to the header not ending square and parallel in the car. For proper system fit, you collectors must run parallel with your rocker panels.

5. Finish the system by making all your final adjustments to position the x-pipe, mufflers and tailpipes. Now tighten all the clamps (Warning: tightened clamps will leave marks in the tubing, making removal or adjustments extremely difficult) or for the best fit weld all the slip joints. The 409 stainless steel system can be welded with your standard mig welder.

6. Note: This kit requires the use of PYPES tip number EVT87 and EVT86, or one similar to exit properly through the valance cutouts.

Now it's time to fire up that muscle car and enjoy your new Pypes Performance Exhaust.

- (A) Collector Extensions
- (B) X-pipe Assembly
- (C) Mufflers
- (D) Tailpipes
- (E) EVT87 Tips (optional)

